



*Universal Slide*



*SOLA Light Mount*



*Universal Slide*



*SOLA Light Mount*



*Inodive LED Light  
Mounted on Slide*

***10130-01***



*Inodive LED Light  
Mounted on Slide*

***10130-01***




# INODIVE LED

## 10130-00

<b>LED Bulb</b>	CREE XPG-R5 3W
<b>Output</b>	10 to 300 Lumens
<b>Battery</b>	3 X AAA Size Alkaline
<b>Switch</b>	Sliding Magnetic switch
<b>Beam Angle</b>	4.6 degree
<b>Burn Time</b>	1 hour at full power
<b>Weight</b>	146 g (with battery)
<b>Light Body</b>	T6061-T6 Anodized Aluminum
<b>Depth Tested</b>	100 Meters

- (1) Insert 3 AAA batteries into the battery holder observing the correct polarity shown on the battery holder.
- (2) Use the same brand alkaline batteries in the battery carrier. Do not mix old and new battery's.
- (3) Clean and lubricate O-Rings with clean silicone grease each time the light is opened.
- (4) Move the magnetic switch forward to turn on and increase the brightness. Move switch all the way to the rear to turn light off



**\*The light must be rinsed with clean fresh water after each dive \***


This light is used with the Innovative Dive Equipment Accessory Rail System. It is also suitable for a back up light clipped to a BC, or carried in a BC pocket. **Battery's are not included. For best results Please use alkaline battery's only.**

# INODIVE LED

## 10130-00

<b>LED Bulb</b>	CREE XPG-R5 3W
<b>Output</b>	10 to 300 Lumens
<b>Battery</b>	3 X AAA Size Alkaline
<b>Switch</b>	Sliding Magnetic switch
<b>Beam Angle</b>	4.6 degree
<b>Burn Time</b>	1 hour at full power
<b>Weight</b>	146 g (with battery)
<b>Light Body</b>	T6061-T6 Anodized Aluminum
<b>Depth Tested</b>	100 Meters

- (1) Insert 3 AAA batteries into the battery holder observing the correct polarity shown on the battery holder.
- (2) Use the same brand alkaline batteries in the battery carrier. Do not mix old and new battery's.
- (3) Clean and lubricate O-Rings with clean silicone grease each time the light is opened.
- (4) Move the magnetic switch forward to turn on and increase the brightness. Move switch all the way to the rear to turn light off




**\*The light must be rinsed with clean fresh water after each dive \***

This light is used with the Innovative Dive Equipment Accessory Rail System. It is also suitable for a back up light clipped to a BC, or carried in a BC pocket. **Battery's are not included. For best results Please use alkaline battery's only.**

**This is the recommended setup for the clamp used to mount the Inodive LED light.**

Light Mount held by 2  
6-32X 5/16" Phillips  
head screws



A screwdriver or a small 6mm wrench can be used to tighten the clamp.

**\*The Inodive Slide offers many different Mounting solutions. The one shown is for the Inodive Light.**

**This is the recommended setup for the clamp used to mount the Inodive LED light.**

Light Mount held by 2  
6-32X 5/16" Phillips  
head screws



A screwdriver or a small 6mm wrench can be used to tighten the clamp.

**\*The Inodive Slide offers many different Mounting solutions. The one shown is for the Inodive Light.**